

## New Method for Synthesizing HSN608 Anticancer Agent, HSN608s

**Track Code:** 2020-THOM-69095

**Categories:**

- Chemistry and Chemical Analysis
- Pharmaceuticals

**Keywords:**

- Accelerated Synthesis
- biopharmaceutical
- Biopharmaceutical Manufacturing
- Blood Cancer
- Cancer
- Cancer Drug
- Chemical Synthesis
- Chemistry and Chemical Analysis
- DESI
- Drug Development
- Drug Manufacturing
- high throughput
- High Throughput Synthesis
- Medicinal Chemistry
- Molecular Chemistry
- Organic Chemistry
- Patient Care
- Pharmaceutical Research
- Pharmaceuticals

Researchers at Purdue University have developed a new high-throughput method for continuous synthesis of an alkynyl naphthyridine anticancer agent, HSN608. HSN608 is a drug agent that shows promise as a treatment for Fms-like tyrosine kinase 3 (FLT3) driven cancers including acute myeloid leukemia (AML). There remains an unmet need to safely scale-up production of HSN608. Its synthesis requires complex amide and Sonogashira coupling reactions that are traditionally catalyzed by dangerous reagents such as palladium and copper, which can lead to creation of explosive byproducts. In addition, liquid chromatography-mass spectrometry (LC-MS) is currently used to validate the composition of HSN608 during its synthesis but is limited to analyzing 384 reactions in 33 hours. Purdue researchers implement desorption electrospray ionization-mass spectroscopy (DESI-MS), which can analyze up to 6,144 reactions in less than 2.5 hours, to optimize reaction conditions. The optimized reaction safely and rapidly induces

amide and Sonogashira coupling through a two-step telescoping sequence to quickly synthesize HSN608. The new high-throughput microscale technique achieves 10-fold higher workload and 5-fold higher reduction in catalyst and co-catalyst loading steps, enabling approximately 8 mg of HSN608 to be produced per hour in up to 55 hours of continuous operation.

**Advantages:**

- Safe
- Cost-Efficient
- Scalable
- Continuous Production

**Potential Applications:**

- Drug Discovery
- Life Science Research
- Chemical Synthesis

**Technology Validation:**

The two-step telescoping sequence used to promote amide and Sonogashira coupling has been validated with DESI-MS as well as subsequent HSN608 product yield (8mg/hour). The system has also been tested in continuous operation for up to 55 consecutive hours.

**Recent Publication:**

"Use of High-Throughput Tools for Telescoped Continuous Flow Synthesis of Alkynyl naphthyridine Anticancer Agent, HSN608"

Journal of Organic Process Research & Development

American Chemical Society

DOI: 10.1021/acs.oprd.0c00289

**People:**

- Thompson, David Harley (Project leader)
- Biyani, Shruti
- Qi, Qingqing
- Sintim, Herman O

**Intellectual Property:**

**Application Date:** May 13, 2021

**Type:** PCT-Gov. Funding

**Country of Filing:** WO

**Patent Number:** (None)

**Issue Date:** (None)

**Application Date:** May 19, 2020

**Type:** Provisional-Gov. Funding

**Country of Filing:** United States

**Patent Number:** (None)

**Issue Date:** (None)

**Contact OTC:**

Purdue Office of Technology Commercialization  
The Convergence Center  
101 Foundry Drive, Suite 2500  
West Lafayette, IN 47906

Phone: (765) 588-3475

Fax: (765) 463-3486

Email: [otcip@prf.org](mailto:otcip@prf.org)